

TIMBERWOOL

PAINTING INSTRUCTIONS

Timberwool™ Wood Fiber Panels will improve the acoustics and the aesthetics of any interior space. Every panel is sealed with clear coat, so they are ready to paint. No need to apply additional primer! The wood fibers are a natural material, with slight variations in color – so painting is expected anywhere aesthetics are a priority. The finished panels look great and can be customized to fit the décor in just about any room.

The best way to apply primer and paint is using spray equipment with non-diluted latex paint. Because the panels are already primed on all 6 sides (back, front, and edges), you will only need to use a latex primer if you are making cuts to the material.

Use a high volume low pressure (HVLP) sprayer or airless spray equipment indoors to cover a large square footage quickly. An air assisted sprayer will give a deeper, more consistent color because it will force the paint between the wood fibers. We do not recommend brushing or rolling paint onto Timberwool. The best approach is to spray the panel with a fine tip spray nozzle from all directions. If you were looking at the panel like a compass, go east-to-west, west-to-east, north-to-south, and south-to-north. Next spray diagonally across the panel from corner-to-corner for each corner. This application method will use the least amount of paint while delivering a deep, consistent color.

Applying a second coat will not reduce acoustic performance. Additional painting instructions may require you to contact the paint or primer manufacturer.



QUESTIONS?
CALL 1-800-679-8511
TO SPEAK TO A
SECOND SKIN
EXPERT.

PANELS ARE
SEALED WITH
CLEAR COAT
AND ARE
**READY
TO PAINT!**